# Extract\_Frames

August 19, 2020

# 0.0.1 This program is to extract frames from recorded videos

```
[1]: import cv2
```

## 0.0.2 Create a VideoCapture object and read from input file

```
[6]: vidObj = cv2.VideoCapture('../Data/Raw/Videos/IMG_7970.MOV')
```

#### 0.0.3 Check if video file is opened successfully

```
[7]: if (vidObj.isOpened()== False):
    print("Error opening video file")
```

#### 0.0.4 Read counter from config file

4514

#### 0.0.5 Create Frames directory if not present

```
[9]: import os
  path = "../Data/Raw/Frames"
  if os.path.exists(path) == False :
      mode = 0o666
      os.mkdir(path, mode)
      print("Directory '% s' created" % path)
```

## 0.0.6 Check frames per second for the video

```
[10]: fps = vidObj.get(cv2.CAP_PROP_FPS)

# For OpenCV 3, you can also use the following
# double fps = video.get(CAP_PROP_FPS);

print ("Frames per second using video.get(cv2.CAP_PROP_FPS) : {0}".format(fps))
```

Frames per second using video.get(cv2.CAP\_PROP\_FPS) : 29.974048442906575

#### 0.0.7 Cehck if frames are extracted

```
[]: success = 1
  frame = 1
  while success:
    success, image = vidObj.read()
    # Saves the frames with frame-count
    if frame%10 == 0:
        print("Saving frame frame_%d.jpg. " % counter)
        cv2.imwrite("../Data/Raw/Frames/frame_%d.jpg" % counter, image)
        counter += 1
    frame += 1
```

#### 0.0.8 Write the counter back to the config file

#### 0.0.9 Release Video

```
[13]: vidObj.release()
print ("Done!")
```

Done!

#### 1 OR

1.0.1 Read all video files at once and start extracting the frames per second out of the video being read.

```
[]: counter = 0
with open('../miscFiles/Count.txt', 'r') as inp:
    counter = int(inp.read())
```

```
listDir = "../Data/Raw/Videos"
listing = os.listdir(listDir)
for vid in listing:
    vid = listDir + "/" +vid
    vidObj = cv2.VideoCapture(vid)
    if (vidObj.isOpened()== False):
        print("Error opening video file")
    success = True
    frame = 1
    while success:
        success, image = vidObj.read()
        # Saves the frames with frame-count
        if frame%30 == 0:
            print("Saving frame frame_%d.jpg. " % counter)
            cv2.imwrite("../Data/Raw/Frames/frame_%d.jpg" % counter, image)
            counter += 1
        frame += 1
```

```
[6]: with open('../miscFiles/Count.txt', 'w') as outp:
    #count = str(counter)
    outp.write(str(counter))

vidObj.release()
print ("Done!")
```

Done!